


How to succeed

- Read the Chapter ahead of lectures
- Come to class
- **Start paper early**
- Study groups
- Prepare exams
- Don't cheat, plagiarize, or otherwise participate in un-ethical behavior
- **Learn with Internet: Wikipedia, google(baidu)...**
- Ask questions and Think skeptically

Important Points from Last Lecture


- Polymer Crystals
- Melting of Polymers



Introduction to Polymer Materials

Lecture 4-5: Solid State Properties III

SUN Dazhi



Polymer Phases

- **Viscous Liquid**

Polydimethylsiloxane $T_g = -123^\circ \text{C}$; $T_m = -40^\circ \text{C}$

- **Elastomeric**

Polyisoprene $T_g = -73^\circ \text{C}$

Polybutadiene, $T_g = -85^\circ \text{C}$

Polychloroprene, $T_g = -50^\circ \text{C}$

Polyisobutylene, $T_g = -70^\circ \text{C}$

- **Amorphous Glassy**

Polystyrene $T_g = 100^\circ \text{C}$

Polymethyl methacrylate, $T_g = 105^\circ \text{C}$



- ***Semi-Crystalline***

Nylon 6,6, $T_g = 50^\circ \text{C}$; $T_m = 265^\circ \text{C}$

PET, $T_g = 65^\circ \text{C}$; $T_m = 270^\circ \text{C}$


Glass-Rubber-Liquid

- Amorphous plastics have a complex thermal profile with 3 typical states:




Glass-Rubber-Liquid

- Crosslinked polymers




Mechanical Properties



Transient Testing

Resilience of Cured Elastomers




- Resilience tests reflect the ability of an elastomeric compound to store and return energy at a given frequency and temperature.


Resilience of Cured Elastomers

Change of rebound resilience (h/h_0) with temperature T for:

1. *cis*-poly(isoprene);
2. poly(isobutylene);
3. poly(chloroprene);
4. poly(methyl methacrylate).



Types of Polymers





Ballpark Comparisons

- **Tensile strengths**

Polymers: $\sim 10 - 100$ MPa

Metals: 100's - 1000's MPa

- **Elongation**

Polymers: up to 1000 % in some cases

Metals: $< 100\%$

- **Moduli (Elastic or Young's)**

Polymers: ~ 10 MPa - 4 GPa

Metals: $\sim 50 - 400$ GPa

Stress Strain Studies




FIG. 10. Tensile test of wire by Leonardo da Vinci.





FIG. 14. Galileo's illustration of tensile test.



Stress-Strain Curve




- Initial slope is the Young's Modulus (E' or sometimes G)
- TS = tensile strength
- σ_y = yield strength
- Toughness = Energy required to break (area under curve)

Compression vs. Tensile Tests


Stress-strain curves are very dependent on the test method



- Tensile testing is most sensitive to material flaws and microscopic cracks.
- Compression tests tend to be characteristic of the polymer, while tension tests are more characteristic of sample flaws.



Stress Strain Graphs


**Chains in neck align
along elongation
direction:
strengthening**





- A - upper limit for stress-strain linearity
- B - upper limit for reversibility of deformations
- C - fracture point


Ductility & Elongation (E_L)



$E_L < 5\%$ Brittle
 $E_L > 5\%$ Ductile


Thermosets = strong & brittle
Not Ductile

Thermoplastics = depends on T




Elastomer Molecules

High entropy



(a)

Low entropy




(b)

Low energy

High energy

Elastomer: TENSILE RESPONSE



- Compare to responses of other polymers:
 - brittle response (aligned, cross linked & networked case)
 - plastic response (semi-crystalline case)

True Stress-strain Curve



Figure 6-7 Neck down of a tensile test specimen within its gage length after extension beyond the tensile strength. (Courtesy of R. S. Wortman)





Figure 6-8 True stress (= load divided by actual area in the necked-down region) continues to rise to the point of fracture, in contrast to the behavior of engineering stress. (After R. A. Flinn/P. K. Trojan: Engineering Materials and Their Applications, 2nd Ed., Copyright © 1981, Houghton Mifflin Company, used by permission.)

YOUNG'S MODULI: COMPARISON



Linear Elasticity: Poisson Effect

- **Hooke's Law:** $\sigma = E \epsilon$

- **Poisson's ratio, ν :**

$$\nu = -\frac{\text{width strain}}{\text{axial strain}} = -\frac{\Delta w / w}{\Delta l / l} = -\frac{\epsilon_L}{\epsilon}$$

metals: ~ 0.33


ceramics: ~ 0.25

polymers: ~ 0.40

Units:

E: [GPa] or [psi]

ν : dimensionless



Why does ν have minus sign?

Poisson Ratio: materials specific

Metals: Ir W Ni Cu Al Ag Au
0.26 0.29 0.31 0.34 0.34 0.38 0.42

generic value $\sim 1/3$

Solid Argon: 0.25

Covalent Solids: Si Ge Al_2O_3 TiC
0.27 0.28 0.23 0.19

generic value $\sim 1/4$

Ionic Solids: MgO 0.19



Silica Glass: 0.20

Polymers: Network (Bakelite) 0.49 Chain (PE) 0.40


Elastomer: Hard Rubber (Ebonite) 0.39 (Natural) 0.49


Negative poisson's ratio

- foams




Mechanical properties are sensitive to temperature






- Lower elastic modulus, yield and ultimate properties
- Greater post-yield deformability
- Greater failure strain




Soft and weak



Hard and brittle



Soft and tough




Hard and strong



Hard and tough


Properties depend on amount of cross-linking




Polymers: Thermal Properties


- In the liquid/melt state enough thermal energy for random motion (Brownian motion) of chains
- Motions decrease as the melt is cooled
- Motion ceases at “glass transition temperature”
- Polymer hard and glassy below T_g , rubbery above T_g

Thermal Properties






1. Crystallization and melting of crystalline polymers.
2. Glass transition of amorphous polymers.



Typical Thermogram of PET

Differential Scanning Calorimetry (DSC)



A thermal analysis technique suited for observing the melting behavior of polymers.



The observed melting behavior of polymers is dependant on the previous thermal history due to its role in crystallite size and total degree of crystallinity.

Thermo-mechanical Properties


Amorphous v Crystalline Polymers



Thermal Expansion

- If a part is to be produced within a close dimensional tolerance, careful consideration of thermal expansion/contraction must be made.
- Parts are produced in the melt state, and solidify to amorphous or semi-crystalline states. Changes in density must be taken into account when designing the mold.

Thermal Expansion



Thermal Expansion

Metals	Coefficient of Expansion
Aluminum	23.5
Brass	18.8
Copper	16.7
Steel	10.8
Plastics	
Poly(vinylidene chloride)	190 - 200
Polyethylene	110 - 250
Polystyrene	60 - 80
Polyamide (nylon)	90 - 108
Phenolic (thermoset)	30 - 45

Heat Distortion Temperature

- The maximum temperature at which a polymer can be used in rigid material applications is called the softening or heat distortion temperature (HDT).
- A typical test (plastic sheeting) involves application of a static load, and heating at a rate of 2°C per min.
- The HDT is defined as the temperature at which the elongation becomes 2%.

Heat Distortion Temperature

- A: Rigid poly(vinyl chloride)
50 psi load.
- B: Low-density poly(ethylene)
50 psi load.
- C: Poly(styrene-co-acrylonitrile)
25 psi load.
- D: Cellulose acetate
(Plasticized) 25 psi load.

